

Supporti per ventose - Serie MF

Fittings for suction cups - MF Series

Art =	Ventosa <i>Suction cup</i>	+ Supporto <i>+ Fitting</i>	Anello di rinforzo <i>Reinforcement ring</i>
MF 25 98	MF 25 35	SUF 30 98	SUF 30 19
MF 25 00	MF 25 35	SUF 30 00	SUF 30 19
MF 25 10	MF 25 35	SUF 30 10	
MF 25 20	MF 25 35	SUF 30 18	SUF 30 19
MF 25 60	MF 25 35	SUF 30 60	SUF 30 19
MF 25 61	MF 25 35	SUF 30 61	SUF 30 19
MF 25 63	MF 25 35	SUF 3063	SUF 30 19
MF 25 64	MF 25 35	SUF 30 64	SUF 30 19
MF 25 90	MF 25 35	SUF 30 90	SUF 30 19
MF 25 91	MF 25 35	SUF 30 91	SUF 30 19
MF 25 93	MF 25 35	SUF 30 93	SUF 30 19
MF 31 98	MF 31 35	SUF 30 98	SUF 30 19
MF 31 00	MF 31 35	SUF 30 00	SUF 30 19
MF 31 10	MF 31 35	SUF 30 10	
MF 31 20	MF 31 35	SUF 30 18	SUF 30 19
MF 31 60	MF 31 35	SUF 30 60	SUF 30 19
MF 31 61	MF 31 35	SUF 30 61	SUF 30 19
MF 31 63	MF 31 35	SUF 30 63	SUF 30 19
MF 31 64	MF 31 35	SUF 30 64	SUF 30 19
MF 31 90	MF 31 35	SUF 30 90	SUF 30 19
MF 31 91	MF 31 35	SUF 30 91	SUF 30 19
MF 31 93	MF 31 35	SUF 30 93	SUF 30 19

Art =	Ventosa <i>Suction cup</i>	+ Supporto <i>+ Fitting</i>	Anello di rinforzo <i>Reinforcement ring</i>
MF 44 99	MF 44 35	SUF 45 99	SUF 40 19
MF 44 00	MF 44 35	SUF 40 00	SUF 40 19
MF 44 10	MF 44 35	SUF 40 10	
MF 44 20	MF 44 35	SUF 40 18	SUF 40 19
MF 44 70	MF 44 35	SUF 40 70	SUF 40 19
MF 44 71	MF 44 35	SUF 40 71	SUF 40 19
MF 44 73	MF 44 35	SUF 40 73	SUF 40 19
MF 44 74	MF 44 35	SUF 40 74	SUF 40 19
MF 44 80	MF 44 35	SUF 40 80	SUF 40 19
MF 44 81	MF 44 35	SUF 40 81	SUF 40 19
MF 44 83	MF 44 35	SUF 40 83	SUF 40 19
MF 44 84	MF 44 35	SUF 40 84	SUF 40 19
MF 44 90	MF 44 35	SUF 40 90	SUF 40 19
MF 44 91	MF 44 35	SUF 40 91	SUF 40 19
MF 44 93	MF 44 35	SUF 40 93	SUF 40 19
MF 44 94	MF 44 35	SUF 40 94	SUF 40 19